

LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE
153.5631	MIDA	315	TSA-P	695	FMX-M / FMX-MS	345121	PHC-01
185	153 / 153-SS	318	FSA-P	874	FCF-P	445001	CSC-02
215	TCD	322	SCA-P	875	TCF-P	571007	PMG-KB-01-Q2S
216	FCD	324	FCA-P	895	FMX-LP	880027	BLR-406-G
217	FSD	325	TCA-P	997	ANM58	880028	BLR-412-G
218	TSD	326	TCA	999	ANX58-UL	00970023	PUL-04
221	TCD-P	327	ANT / ANT-UL / APT	2935	TFLN / TFLP	01000056	CSC-02
224	FSE-P	332	SCA	2938	TFLS	01000057	CNR-01
225	FSE	337	ANK	30055	ACB-V	01020071	CSA-01
226	FCD-P	354	BLC-16	30056	ACB-N	01020074	CNA-03
227	FSD-P	362	FSX	30090	CBS-P	01020076	CSA-01
228	TSD-P	370	FMR-E / FMS-E	30128	ACB-H	01050003	CSG-01
229	TSE	372	TMR-E	30144	MOCB-24-N	01110005MR	CSC-05
230	TSE-P	373	FMR / FMS	30171	ACB-N	01110501	CSC-01
234	MSC	374	TMR / TMS	30172	ACB-V	01110506	CSC-01
235	FSC	382	TMS-E	30181	MOCB-24-V	01500145	LPA-09B-14RU
236	FSC-P	392	TMR-R-E / TMS-R-E	30406	MRCB-24-N	01500274	LPC-02B-16R
238	TSC-P	395	FMR-R / FMS-R	30409	ACB2-PL	01520001	BLX-01-C
239	TSC	396	TMR-R / TMS-R	30418	ACBP4-PM	01520900	BLX-C
251	FXG	430	T1206	30423	MRCB-24-H	01550109	LPA-09B-14R-9A
257	ANR / ANR-UL / APR	437	F1206	30427	ACBP-V	01550114	LPA-09B-14R-14A
283	TFLD	438	F0603	30525	MOCB-24-H	01550120	LPA-09B-14R-20A
287	ANR / ANR-UL / APR	467	F0603	46377	BLC-1xx	02981003	BLC-07B
293	TFLF	471	MXG	46379	BLC-1xx-G	02981028	BLC-10
294	TFLM	473	TXG	87128	CBB-P	03450121	PHC-01
295	TFLB	481	FPT / FPT-C	100056	CSC-02	04450001	CSC-02
297	ANM / ANM-UL / APM	495	FMX	100057	CNR-01	04980900	BLC-61
298	MGGA / MGGA-B	498	MIDA	105003	CSG-01	04980903	BLC-06B
299	ANX / ANX-UL / APX	662	FMR-E / FMS-E	111501	CSC-01	04981038	BLC-65
301	FSH	663	TMR-E / TMS-E	111506	CSC-01	05600000	BMS
307	FSO	665	TMR / TMS	150145	LPA-09B-14RU	05620000	BMS-R
311	FSA	672	FSF-P	150274	LPC-02B-16R	05710007	PMG-KB-01-Q2S
312	FSA	673	TSF-P	155109	LPA-09B-14R-9A	0603L	R0603 / R0603LR
313	TSA	674	FCF-P	155114	LPA-09B-14R-14A	0805L	R0805 / R0805LR
314	FCA	675	TCF-P	155120	LPA-09B-14R-20A	097023	PUL-04

LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE	LITTELFUSE	OPTIFUSE
0FHA0001	LPR-01	AGX	FSX	KLK	FPK	MIN LP	ANS / ANS-UL
0FHA0001HXGLO	LPR-13C-12R	ATO	ANR / ANR-UL / APR	KLKR	FPK-R	MIN-GLO	ANM-I / APM-I
0FHA0002	LPR-01	ATO-GLO	ANR-I / APR-I	L600C	BPK-R-100	miniSMDC	R1812 / R1812LR
0FHA0200	LPR-08	ATOF	ANR / ANR-UL / APR	LFFB-3	BLC-09	nanoSMDC	R1206 / R1206LR
0FHM0001	LPM-01	CBF	MOCB2-PCL	LFFB0003	BLC-09	PAL0	TFLF
0FHM0001HXGLO	LPM-11C-14R	CNL	ANE / ANE-M / ANF	LFFB003	BLC-09	PAL1	TFLM
0FHM0002	LPM-01	CTB	CBW28	LHFB-1	LPA-03	PAL2	TFLB
0FHM0003	LPM-01	FCB	MOCB2-PL	LHFB0001	LPA-03	PAL3	TFLS
0FNY0020	LPA-05W-12R	femtoSMDC	R0603 / R0603LR	LHFB001	LPA-03	PAL4	TFLD
0FNY0030	LPA-05W-12R	FHA-1	LPR-01	LJCA	FMX-LP	PAL5	TFLN / TFLP
0MAH0001	LPX-02	FHA-2	LPR-01	LMIN	ANS / ANS-UL	picoSMDC	R0805 / R0805LR
102071	CSA-01	FHA001-GLO	LPR-13C-12R	LPSC	BPK-R-500	RGEF	RS16
102074	CNA-03	FHAC-1	LPR-02	LPSM	BPK-500	RHEF	RS16HT / RS30HT
102076	CSA-01	FHAC-2	LPR-02	LR4	RALR	RKEF	RS60SB
1206L	R1206 / R1206LR	FHAC0001	LPR-02	LTP	RALT	RTEF	RS36
1210L	R1210 / R1210LR	FHAC0002	LPR-02	LVR	RS240	RUEF	RS30
16R	RS16	FHAS100	LPR-05B-12R	LVRL	RS120	RUSBF	RSUSB
1812L	R1812 / R1812LR	FHLM0200	LPS-08	MAB1	BLX-01-C	RXEF	RS60RB
215XE	TCD-P	FHM-1	LPM-01	MAH-1	LPX-02	SFE	FSO
216XE	FCD-P	FHM-2	LPM-01	MAXI	ANX / ANX-UL / APX	SMD	R2920
217XE	FSD-P	FHM-3	LPM-01	MAXI-GLO	ANX-I / APX-I	SRP	RASR
218XE	TSD-P	FHM001-GLO	LPM-11C-14R	MCAS	FMX-M / FMX-MS	STD	RASR
234XE	MSC-P	FHM20200	LPT-08	MCB	ACBM-PX	TRF250	RS250
250R	RS250	FHMS200	LPM-05B-12R	MEGA	MGGA / MGGA-B	TRF600	RS600
2920L	R2920	FHMS201	LPM-05B-14R	MIB	MOCBP4-PM	UCB	MOCB2-PL3
30R	RS30	FLNR	TRK5-NR	microSMD	R1210 / R1210LR	VLR	RAVL
600R	RS600	FLQ	TPK	MIDI	MIDA	VTP	RAVT
60R	RS60RB	FN Y-20	LPA-05W-12R	MIN	ANM / ANM-UL / APM		
72R	RS90	FN Y-30	LPA-05W-12R				
812xxx	ACB-N	GBC	APG				
813xxx	ACB-H	JCAS	FMX				
AGA	FSH	JLLN	F3T				
AGC	FSA	JLLS	F6T				
AGU	FSG	JTD	T6J				
AGW	FSW	KLDR	TPK-R				

This guide is designed as a reference tool to help users identify the closest OptiFuse equivalent to competitive part numbers based on form, fit, and function.

Users are responsible for verifying all product specifications, ratings, and certifications to ensure suitability for their specific application before making substitutions.

For additional assistance, application support, or more detailed technical information, please visit www.optifuse.com or contact our application engineering team at engineering@optifuse.com.