
Type PMA-DS-06-SOS Panel Mount Fuse Holder ¼" x 1¼" (6.3 x 32mm) Fuses Driver / Screw



www.optifuse.com (6

(619) 593-5050





-Operation beyond the specified maximum ratings or improper use may result in damage and possible electrical arcing and/or flame.

-Fuse Holders are not intended for circuit disconnect. All power should be disconnected before removing fuse. -Avoid contact of Fuse Holder with chemical solvent. Prolonged contact may damage the device performance.